



MANUFACTURER	ADAPTERS REQUIRED*
Audi	<a href="#">BA05</a>
BMW/Mini	<a href="#">BA05</a>
GM/Chevrolet/Cadillac/GMC/Buick/Pontiac	<a href="#">BA04</a> , <a href="#">BA05</a>
Chrysler/Dodge/Ram/Jeep	<a href="#">BA01</a> , <a href="#">BA04</a> , <a href="#">BA05</a>
Daewoo	<a href="#">BA04</a> , <a href="#">BA05</a>
Ferrari	<a href="#">BA05</a>
Fiat	<a href="#">BA05</a>
Ford	<a href="#">BA02</a> , <a href="#">BA03</a> , <a href="#">BA04</a> , <a href="#">BA05</a>
Honda	<a href="#">BAH1</a>
Hyundai	<a href="#">BA03</a>
Jaguar	<a href="#">BA05</a>
Kia	<a href="#">BA03</a> , <a href="#">BA05</a>
Lamborghini	<a href="#">BA05</a>
Land Rover	<a href="#">BA05</a>
Lexus	<a href="#">BA10</a>
Maserati	<a href="#">BA05</a>
Mazda	<a href="#">BA03</a> , <a href="#">BA04</a> , <a href="#">BA05</a>
Mercedes-Benz	<a href="#">BA05</a>
Mitsubishi	<a href="#">BA03</a>
Nissan	<a href="#">BA03</a> , <a href="#">BA05</a> , <a href="#">BA13</a>
Porsche	<a href="#">BA05</a>
Renault	<a href="#">BA05</a>
Rover	<a href="#">BA03</a>
Saab	<a href="#">BA03</a>
Subaru	<a href="#">BA03</a>
Suzuki	<a href="#">BA03</a>
Toyota	<a href="#">BA10</a> , <a href="#">BA05</a>
Volvo	<a href="#">BA05</a>
Volkswagen	<a href="#">BA05</a>



### BAK8

**Brake Adapter Kit  
8 Adapters  
(Probe Style)**



### BAK5

**Brake Adapter Kit  
5 Adapters  
(Probe Style)**

Domestic Kit  
Does not include Honda,  
Toyota, or Nissan  
(BAH1, BA10, BA13)